

1/8th SCALE GAS POWERED 4WD RACING TRUGGY MBX-6T PARTS LIST

1/8スケール4WDレーシングトラギー MBX-6Tパーツリスト

E0061 	E0062 	E0063
B0104 	E0104-B 	
C0107D 	E0117 OPT 	
B0118 	B0119 	
E0123 	E0124 	C0129
E0135 		
E0143 	E0144 	
E0146 		
E0147 		

- E0061 MBX-6T INSTRUCTION MANUAL
- E0062 MBX-6T DECAL
- E0063 MBX-6T DECAL 3pcs.
- B0104 FUEL FILTER S
- E0104-B CENTER DIFF. MOUNT
- C0107D PIVOT BALL φ7mm
- E0117 TITANIUM REAR UPPER ARM
- B0118 AIR FILTER SET
- B0119 AIR FILTER
- E0123 LOWER ARM SHAFT
- E0124 REAR LOWER ARM SHAFT S
- C0129 FRONT UPPER ARM ROD
- E0135 SUS. ARM SPACER
- E0143 FRONT LOWER ARM SUPPORT
- E0144 REAR LOWER ARM SUPPORT
- E0146 GEAR BOX
- E0147 LOWER ARM MOUNT

E0151 	E0152
E0153 	E0154
E0155 	E0156
E0157 	E0159
E0160 	E0161
E0162 	E0163 OPT
E0164 OPT 	E0165 OPT
E0166 OPT 	E0167 OPT
E0168 OPT 	E0169 OPT
E0170 OPT 	E0171 OPT
E0172 OPT 	

- E0151 FRONT UPRIGHT
- E0152 REAR UPRIGHT
- E0153 FRONT TENSION ROD
- E0154 BUSH SET
- E0155 ANTI-ROLL BAR LINK
- E0156 FRONT UPPER PLATE
- E0157 CENTER DIFF. MOUNT PLATE
- E0159 ADJUST NUT
- E0160 FRONT LOWER KINGPIN BALL
- E0161 FRONT TRACK WIDTH ADJUST SPACER
- E0162 FRONT UPPER ARM SHAFT
- E0163 FRONT ANTI-ROLL BAR φ2.2mm
- E0164 FRONT ANTI-ROLL BAR φ2.3mm
- E0165 FRONT ANTI-ROLL BAR φ2.4mm
- E0166 FRONT ANTI-ROLL BAR φ2.5mm
- E0167 FRONT ANTI-ROLL BAR φ2.6mm
- E0168 REAR ANTI-ROLL BAR φ2.7mm
- E0169 REAR ANTI-ROLL BAR φ2.8mm
- E0170 REAR ANTI-ROLL BAR φ2.9mm
- E0171 REAR ANTI-ROLL BAR φ3.0mm
- E0172 REAR ANTI-ROLL BAR φ3.2mm

E0173 OPT 	E0173L OPT
E0173R OPT 	E0174
E0175 OPT 	E0176 OPT
E0177 	E0178
E0179 	H0180
E0180 	E0181
E0182 	E0183

- E0173 AL. REAR UPRIGHT SET
- E0173L AL. REAR UPRIGHT L
- E0173R AL. REAR UPRIGHT R
- E0174 WASHER SET
- E0175 FRONT ANTI-ROLL BAR φ2.1mm
- E0176 REAR ANTI-ROLL BAR φ2.6mm
- E0177 AL. FRONT UPPER ARM MOUNT
- E0178 FRONT LOWER ARM
- E0179 REAR LOWER ARM
- E0180 FRONT UPPER ARM
- H0180 REAR UPRIGHT BALL
- E0181 TENSION ROD
- E0182 FRONT UPRIGHT ARM (-4)
- E0183 REBOUND STOP ADJ. SCREW

E0202 	E0206
E0210 	E0219
E0221 	C0222C
E0225 	E0228
E0229 	C0230
E0230 	E0233 OPT
E0234 	E0235 OPT
E0236 	E0237
E0238 	E0242 OPT
E0243 OPT 	T0243
T0244 	E0246
E0247 	

- E0202 CENTER DRIVE SHAFT L (97)
- E0206 DIFF. WASHER SET
- E0210 PIN φ3x16.8 (8pcs.)
- E0219 SELF-LOCKING WHEEL NUT
- E0221 F/ R AXLE SHAFT
- C0222C DIFF. SHAFT
- E0225 JOINT CUP
- E0228 F/ R CUP JOINT
- E0229 CENTER CUP JOINT
- C0230 DIFF. GEAR 10T
- E0233 SPUR GEAR 44T
- E0234 SPUR GEAR 46T
- E0235 SPUR GEAR 48T
- E0236 JOINT BOOTS
- E0237 JOINT PIN (φ2.2x9.8) (FOR E0228/E0229)
- E0238 JOINT PIN (φ2.5x14.8) (FOR E0221/E0242)
- E0242 AL. F/R AXLE SHAFT
- E0243 AL. JOINT CUP
- T0243 S3 O-RING
- T0244 S5 O-RING
- E0246 CENTER UNIVERSAL JOINT (142) SET
- E0247 CENTER DRIVE SHAFT (142)

E0248 	E0249
E0250 	E0251
E0252 	E0255
C0256 	C0257
C0264 	C0265
C0270 	C0271
C0304A 	E0315
E0318 	E0319
E0320 	E0321-B
E0322 	E0323

- E0248 CONICAL GEAR 46T (for MBX6T)
- E0249 BEVEL GEAR 10T (for MBX6T)
- E0250 F/ R UNIVERSAL JOINT (132) SET
- E0251 F/R DRIVE SHAFT (132)
- E0252 WHEEL HUB (14)
- E0255 CENTER UNIVERSAL JOINT (97) SET
- C0256 DIFF. CASE
- C0257 GASKET FOR DIFF.
- C0264 JOINT SHAFT
- C0265 JOINT PIN (FOR E0225/E0243)
- C0270 JOINT PIN (FOR E0202/E0226/E0227/E0247)
- C0271 JOINT PIN (FOR E0222/E0251)
- C0304A BRAKE PLATE
- E0315 SERVO SAVER SPRING
- E0318 SERVO SAVER PLATE
- E0319 BRAKE PAD
- E0320 SERVO SAVER ARM
- E0321-B RADIO BOX
- E0322 RADIO BOX GROMMET
- E0323 RADIO PLATE

E0325 	E0326
E0327 OPT 	C0354
C0356 	C0361 OPT
E0405 	E0410
E0411 	E0413
E0414 	B0431
H0471 	H0513
E0517 	E0518
E0519 	E0520
C0529A 	

- E0325 BRAKE CAM
- E0326 SERVO SAVER PIPE
- E0327 AL. SERVO SAVER SHAFT
- C0354 BRAKE DISK
- C0356 SERVO SAVER SHAFT
- C0361 BRAKE PAD BLUE
- E0405 WING STAY BRACE
- E0410 FRONT BUMPER
- E0411 WING STAY
- E0413 CHASSIS MBX-6T
- E0414 STONE GUARD
- B0431 3mm CONE WASHER
- H0471 REAR BODY MOUNT ARM PIN
- H0513 SPRING ADJUSTER
- E0517 FRONT DAMPER SHAFT
- E0518 REAR DAMPER SHAFT
- E0519 OIL SEAL CAP
- E0520 OIL SEAL SET
- C0529A LINK BALL

