















PARTS

★ Specifications are subject to change without notice.




- Chassis×1
9404934
- Fuel tank×1
7644023
- Body×1
1824101
- Wing×1
9334126
- Body sticker×1
1424443
- Masking sticker×1
1424444
- Caution sticker×1
1420253
- Aluminum glass tape ·×1
(50x70mm) 53351
- Antenna pipe×1
6094007

A 1~7

Rear shock tower ·×1
9404931

★Extra screws and nuts are included. Use them as spares.







B 8~14

Front shock tower ·×1
9404930


Front stabilizer rod ·×1
9404980

Rear stabilizer rod ·×1
9404981



B**C****15 ~ 22**Front upper deck ×1
9404918Center diff upper deck ×1
9404919**D****23 ~ 27**

D



BD7 ×2
Front coil spring
9404977

BD8 ×2
Rear coil spring
9404978

BD9 ×8
3.5mm Silicone
O-ring
9404989

BD10 ×4
Damper boot
9404992

BD11 ×4
Oil seal
9404994

BD12 ×4
2x6mm Cap screw
9400769

BD13 ×4
2mm Spring washer
9400794

BA23 ×4
3x18mm Cap screw
9400773

BA35 ×4
3mm Lock nut
9804364

BD14 ×4
3mm Washer
50586

BB16 ×4
6mm Ball collar
9804329

E 28~33

Servo plate ·×1
9404917

Double-sided tape
(20x40mm) ·×1
50171

BE1 ×2
Spring (short)
9404986

BE2 ×1
Spring (long)
9404985

BE3 ×1
2x64mm Adjuster rod
9404988

BE4 ×1
2x80mm Adjuster rod
9404987

BE5 ×1
Switch cover
9404990

BE6 ×1
Overflow tube
9404991

BE7 ×2
Tank bushing rubber
9404993

BE8 ×4
2x10mm Cap screw
9400798

BE9 ×1
Brake linkage pipe
6094008

BB11 ×8
3x8mm Button head screw
9400776

BA25 ×14
3x10mm Button head screw
9400777

BA27 ×2
3x15mm Button head screw
9400779

BC21 ×4
3x10mm Countersunk screw
9400782

BB15 ×4
3x3mm Grub screw
50576

BA35 ×1
3mm Lock nut
9804364

BA36 ×12
4mm Washer
9804370

BD14 ×8
3mm Washer
50586

BE10 ×2
2mm Washer
9805758

BE11 ×2
2mm Lock nut
9805889

BE12 ×1
4mm Adjuster
0445563

BE13 ×1
3x42mm Turn-buckle shaft
9400797

BE14 ×3
Rod stopper
9804221

BE15 ×2
6mm Snap pin
9805702

BE16 ×2
3mm O-ring
9805240

F 34~39

Silicone tube (500mm) ·×1
9404998

BF1 ×2
Engine mount
9404927

BF2 ×1
Muffler mount
9404935

BF3 ×4
12mm Wheel nut
9404950

BF4 ×1
Flywheel
9404959

BF5 ×1
3mm Taper washer
9404957

BF6 ×1
Flywheel nut
9404958

BF7 ×1
Taper collet
9404959

BF8 ×3
Clutch shoe
9404960

BF9 ×1
Clutch bell
9404968

BF10 ×1
5x20x0.2mm Shim
9404974

BF11 ×1
5x10x1mm Washer
9404975

BF12 ×1
Muffler mount rod
9404982

BF13 ×3
Clutch spring
9404983

BF14 ×2
1050 Ball bearing
9404999

BB9 ×4
2.5x8mm Cap screw
9400770

BF15 ×5
3x10mm Cap screw
9400771

BB13 ×1
3x8mm Countersunk screw
9400781

BF16 ×4
4x10mm Flange cap screw
9400793

BB15 ×1
3x3mm Grub screw
50576

BF17 ×4
3mm Spring washer
50587

BF18 ×1
5x0.1mm Shim
53587

BF19 ×1
5x0.2mm Shim
53587

BF20 ×1
5x0.3mm Shim
53587

BF21 ×1
3x0.1mm Shim
53585

BF22 ×4
3x0.2mm Shim
53585

BF23 ×1
3x0.3mm Shim
53585

G 40~43

BC22 ×2
3x12mm Countersunk screw
9400783

BA35 ×2
3mm Lock nut
9804364

BG1 ×2
Wing washer
9805631

BG2 ×4
7mm Snap pin
50956

Tool bag

Box wrench ·×1
9404997

Nylon band ·×3
50595

Hex wrench (3.0mm) ·×1
2990058

Hex wrench (1.5mm) ·×1
50038

Grease ·×1
87025

Damper oil (#400) ·×2
53443

Differential oil (#10000) ·×1
53759

Air cleaner filter ·×1
41063

Air cleaner oil ·×1
41063

Liquid thread lock ·×1
54032

Air cleaner parts bag
41063

Air cleaner cap ·×1

Air cleaner housing ·×1

Air cleaner pipe ·×1

3x6mm Screw ·×1

