



## Crankshaft Assembly




## Pull Start Assembly




\*Part 5211 (roller clutch) not included with complete starter assembly packages.


## Air Filter Assembly



## Exhaust Assembly



## EZ-Start™ 2 Assembly



5270 Complete EZ-Start® System. Includes drive unit, controller and wiring harness.

\*Part 5211 (roller clutch) not included with complete starter assembly packages.